

TECHNICAL SUPPORT

aaron@lazerlamps.com / sales@lazerlamps.com
+44 (0)1992 945601 / +44 (0)1992 677374

WHAT'S REQUIRED

- 2x ST8 / Triple-R 1000
- 1x Two Lamp Harness Kit
- 2x Wiring Kit Extension
- 2x 76mm Tube Clamps

Optional:

- 2x 3 Inch Spacer Kit

DIFFICULTY LEVEL



TOOLS REQUIRED



ALLEN KEY SET



METRIC SOCKET SET



WIRE STRIPPERS AND RATCHET CRIMPERS



WIRE CUTTERS



LAZER
HIGH PERFORMANCE LIGHTING

WWW.LAZERLAMPS.COM

+44 (0)1992 677374
sales@lazerlamps.com

Lazer Lamps Ltd, Units 1&2 Harlow Mill Business Centre,
Riverway, Harlow, Essex. CM20 2FD. United Kingdom



MADE IN THE UK



/LAZERLAMPS



/LAZERLAMPS

LAZER
HIGH PERFORMANCE LIGHTING




ISUZU D-MAX
SPORTS BAR INSTALL

FITTING INSTRUCTIONS

PRE-INSTALLATION CHECKS

Ensure battery is disconnected.

WIRING



STEP 1

Locate the headlamp high beam wire which has positive voltage going to the bulb (High beam 12v signal wire is a Pink wire on Left headlight plug - tested on LED headlamps).

STEP 2

Cut the vehicle high beam wire approximately 100mm from the connector, strip wire ends 7mm and twist strands.

STEP 3

Strip wire end from Lazer wiring harness (p/n 2L-LP-120), from relay position 85

STEP 4

Connect all high beam wires from the wiring harness to the pink wire from the back of the left headlight plug using supplied butt connectors.



STEP 5

Connect ground wire from harness to grounding point in engine bay (or on -ve battery terminal).

STEP 6

Connect fused wire to positive terminal on battery. Cable-tie loose wires as required.



STEP 7

Locate relay as pictured:

STEP 8

Route the cable to the sports bar as follows:

Route the wiring along the main harness which runs underneath the Vehicle adjacent to the brake pipes. Secure the wiring as indicated in fig1, fig2, and fig3.



STEP 9

Route the wiring up between the Cab and the load bay area as pictured in fig4.

Cable-tie to the sports bar as required.



MOUNTING YOUR LIGHTS

(These fitting instructions relate to installation of Lazer ST8 Evolution spotlights to the sports bar of the MY17 D-max. Guidelines for mounting lights on older models are available on request from: sales@lazerlamps.com)



STEP 1

Attach the 76mm tube clamps to the sports bar, complete with the lamp centre mounting kits and fixtures supplied. (Optional - 50mm spacers with M8 x80 hex bolts are provided to elevate the lamps higher above the roof line).

STEP 2

Slide the lamps across the centre mounts until central, and fix the lamps by tightening the pre-inserted M5 grub screws.

STEP 3

Rotate the individual lamp mounts, and tube clamps, to achieve a level install, ensuring the lamps point in a straight-ahead direction. Check all fixtures have been tightened.


CONNECTING YOUR LIGHTS

OPTION 1:

Utilising the pre wired connectors making sure the excess wiring is aesthetically secured.

OPTION 2:

For a more bespoke way the wiring can be cut and shortened then using the crimp connectors provided and heat shrunk on all joints as pictured below. Once the joints have been crimped and heat shrunk, cover the wiring from the Spot lamps with the left over sheafing.



TROUBLE SHOOTING

ISSUE: Lamps don't illuminate after wiring system.

- Check that the High Beam wire carrying +ve voltage has been selected, and not the ground wire coming from the bulb.
- Check fuse in harness.
- Check that relay is switching. If not, check there is +ve voltage at relay when main beam lights are activated. If not, then check splice.